



HPSHEAD-P Parts Breakdown

| <u>Key</u> | <u>Part #</u> | <u>Description</u> |
|------------|---------------|-----------------------------|
| A | 733024 | Power Cord |
| B | 410129 | Strain Relief Bushing |
| C | 403003 | ON-OFF Switch |
| D | 160718T | Lamp Housing Bracket |
| E | 160719T | Igniter |
| F | 160720T | Ballast |
| G | 160721T | Igniter/Ballast Compartment |
| H | 203003Y | Light Diffuser Grille |
| I | 160722T | Lamp Socket |
| J | 160723T | Lamp Socket Ring |
| K | 160724T | DLHPS Reflector/Housing |