


HPSHEAD-P Parts Breakdown

<u>Key</u>	<u>Part #</u>	<u>Description</u>
A	733024	Power Cord
B	410129	Strain Relief Bushing
C	403003	ON-OFF Switch
D	160718T	Lamp Housing Bracket
E	160719T	Igniter
F	160720T	Ballast
G	160721T	Igniter/Ballast Compartment
H	203003Y	Light Diffuser Grille
I	160722T	Lamp Socket
J	160723T	Lamp Socket Ring
K	160724T	DLHPS Reflector/Housing



DSDL Arm Parts Breakdown

<u>Key</u>	<u>Part #</u>	<u>QTY. #</u>	<u>Description</u>
A	160713T	2	Internal Support Bracer
B	413019	1	Luminaire Power Receptacle
C	103045	1	Lamp Arm
D	160715T	1	Swivel Bracket W/ Supports
E	10069	2	Wall Arm
F	160716T	1	Arm Stop
G	820213	4	Closure Cap
H	160717T	1	Wall Mount Bracket
I	733016	1	Power Cord
J	413007	3	Strain Relief Bushing